

Hegel H95, H120, H190 RC-5 code table

v2

09.09.2020

System 16 (Preamp 1)																										
Function	Command	Description	HEX-Long																							
Balanced	1	Source select	0000 0073 0000 000C 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Analog 1	0	Source select	0000 0073 0000 000C 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Analog 2	7	Source select	0000 0073 0000 000C 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Coaxial	8	Source select	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Optical 1	6	Source select	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Optical 2	5	Source select	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Optical 3	4	Source select	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
USB	9	Source select	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Network	3	Source select	0000 0073 0000 000C 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Volume Up	16	Volume control	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
	16 (alt)	Volume control (alt)	0000 0073 0000 000C 0020 0040 0020 0CC5																							
Volume Down	17	Volume control	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
	17 (alt)	Volume control (alt)	0000 0073 0000 000C 0020 0040 0020 0CA4																							
Mute	13	Mute toggle	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
	13 (alt)	Mute toggle (alt)	0000 0073 0000 000C 0020 0040 0020 0CA4																							
Mute On	55	Mute on	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Mute Off	56	Mute off	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
IN +	64	Source select	0000 0073 0000 000C 0040 0020 0020 0040 0040 0020 0CC5																							
	64 (alt)	Source select (alt)	0000 0073 0000 000C 0040 0040 0020 0020 0040 0020 0CC5																							
IN -	70	Source select	0000 0073 0000 000B 0040 0020 0020 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
	70 (alt)	Source select (alt)	0000 0073 0000 000B 0040 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Power	79	Power Toggle	0000 0073 0000 000C 0040 0020 0020 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
	79 (alt.)	Power Toggle (alt)	0000 0073 0000 000C 0040 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Power On	77	Power On	0000 0073 0000 000B 0040 0020 0020 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Power Off	78	Power Off	0000 0073 0000 000B 0040 0020 0020 0040 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							

System 19 (Preamp 2)																										
Function	Command	Description	HEX-Long																							
Display	15	Display on/off (hold for off)	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Display Off	14	Display off	0000 0073 0000 000A 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Set Startup Vol	21	Set start up volume	0000 0073 0000 0009 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Set Max Vol	20	Set upper volume limit	0000 0073 0000 0009 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0040 0040 0040 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Factory Reset	31	Resets to factory default	0000 0073 0000 000B 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
Previous Track	50	Playback control	0000 0073 0000 000A 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
	50 (alt)	Playback control (alt)	0000 0073 0000 000B 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Next Track	52	Playback control	0000 0073 0000 000A 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
	52 (alt)	Playback control (alt)	0000 0073 0000 000B 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CC5																							
Play/Pause	53	Playback control	0000 0073 0000 000A 0020 0020 0040 0040 0040 0020 0020 0040 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							
	53 (alt)	Playback control (alt)	0000 0073 0000 000B 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0020 0040 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0020 0040 0020 0CA4																							

Important note

All commands meant to be used repeatedly must be programmed with two separate HEX codes to work as intended. Program your remote so that using the command multiple times in a row alternates between the original and the alternate HEX codes.

Explanation:
 1st use of the command: Use the original HEX code
 2nd use of the command: Use the alternate (alt) HEX code
 3rd use of the command: Use the original HEX code again

By alternating between the two HEX codes in this manner your Hegel device will register each command individually. This will prevent the command from freezing.